


PVE Series 4 for PVG 32, PVG 100 and PVG 120

Technical Information









PVE Series 4 for PVG 32, PVG 100 and PVG 120

Contents - Introduction

Revision History

Date	Page	Changed	Revision
May 2008	9	tabel and text	DB
Jan 2009	16	UDC - UDC2 changed places	
Feb 2009	2009 27 Material number changed		DE

Contents

Contents - Introduction	2
Function	3
Electrical actuation	4
Technical data	8
Fault monitoring system	12
Dimensions	
Connection and activation	16
Activation characteristic	20
Directional indicator	23
Electrical systems	24
System safety	
Code numbers	

Introduction

Product developments based on Sauer-Danfoss' activities in research and development, and design of new components is determined by market and customer requirements, thus contributing to maintaining and extending our leading market position in the field of electro hydraulically operated hydraulic valves.

The technology used in PVE series 4 is based on proven electronic development principles known from e.g. the automobile industry - together with our long experience within electrical activation of hydraulic valves for the mobile market. These factors will not only maintain the high level of quality and reliability experienced with PVE series 2 and 3, but will also give specification improvements for the PVE modules – e.g. the environmental protection.

This catalogue will give you an introduction to the different PVE modules, their functions and technical data.


Sauer-Danfoss accepts no responsibility for possible errors in catalogs, brochures and other printed material. Sauer-Danfoss reserves the right to alter its products without prior notice. This also applies to products already ordered provided that such alterations aren't in conflict with agreed specifications. All trademarks in this material are properties of their respective owners. Sauer-Danfoss and the Sauer-Danfoss logotype are trademarks of the Sauer-Danfoss Group.

^{© 2008} Sauer-Danfoss. All rights reserved. Printed in Europe



Function


The philosophy of Sauer-Danfoss electro hydraulic actuation, type PVE, is integration of electronics, sensors and actuators into a single unit that interfaces directly to the proportional valve body.



Closed loop control

157-497.11

All the proportional actuators feature an integrated feedback transducer that measures spool movement in relation to the input signal, and by means of a solenoid valve bridge, controls the direction, velocity and position of the main spool of the valve. The integrated electronics compensate for flow forces on the spool, internal leakage, changes in oil viscosity, pilot pressure, etc. This results in lower hysteresis and better resolution. Furthermore the electronics enable built in safety like fault monitoring, directional indication and LED light indication.



Principle

In principle the input signal (set-point signal) determines the level of pilot pressure which moves the main spool. The position of the main spool is sensed in the LVDT transducer which generates an electric feed-back signal registered by the electronics. The variation between the set-point signal and feed-back signal actuates the solenoid valves. The solenoid valves are actuated so that hydraulic pilot pressure drives the main spool into the correct position.

Inductive transducer, LVDT

(Linear Variable Differential Transformer). When the main spool is moved, a voltage is in-duced proportional to the spool position. The use of LVDT gives contact-free monitoring of the main spool position. This means an extra-long working life and no limitation as regards the type of hydraulic fluid used. In addition, LVDT gives a precise position signal of high resolution.

Integrated pulse width modulation

Positioning of the main spool in PVEA/PVEH/PVES is based on the pulse width modulation principle. As soon as the main spool reaches the required position, modulation stops and the spool is locked in position.



Electrical Actuation

ON/Off Actuation

With electrical ON/OFF actuation the main spool is moved from neutral to maximum stroke when power is connected.

PVEO, ON/OFF


Main features of PVEO:

- Compact
- Robust operation
- With Hirschmann, Deutsch or AMP connector
- Low electrical power
- As option with directional indicator (DI)

PVEO-R, ON/OFF with hydraulic ramp

Like PVEO, but for applications where longer reaction time is needed.

With electrical proportional actuation the main spool position is adjusted so that it corresponds to an electrical signal – e.g. from a remote control unit.



157-513.10

Proportional Actuation

PVEA, proportional fine


PVEA versions are recommended where among the requirements are fault monitoring, low hysteresis, high resolution but where the reaction time is not critical. Main features of PVEA:

- Inductive transducer
- Integrated pulse width modulation
- · Low hysteresis
- AMP or Deutsch connector
- As option with directional indicator (DI)
- Fault monitoring with transistor output for signal source.
- Low electrical power
- No set-up procedure

157-510.10

PVEH, proportional high


Performance like PVEA but with fast reaction time. Main features of PVEH:



- Integrated pulse width modulation
- Low hysteresis
- Fast reaction time
- Hirschmann, Deutsch or AMP connector
- As option with directional indicator (DI)
- Fault monitoring with transistor output for signal source



No set-up procedure



157-511.10




Electrical Actuation

Proportional Actuation (continued)

PVES, proportional super

PVES versions are recommended for control systems requiring very low hysteresis to obtain a high resolution. For other technical data: see PVEH


• Hirschmann, Deutsch or AMP connector



157-775.10


Hydraulic Principles

PVEO




157-470.10

PVEO-R



157-469.10

PVEO-DI




157-776.10




Electrical Actuation

Hydraulic Principles (continued)


PVEA



PVEA-DI



PVEH/PVES




157-360.10



Electrical Actuation

Hydraulic Principles (continued)

PVEH-DI





PVE Series 4 for PvG 32 DANFOSS Technical Information PVE Series 4 for PVG 32, PVG 100 and PVG 120

Technical Data

Technical Data

The following technical data are from typical test results. For the hydraulic system a mineral based hydraulic oil with a viscosity of 21 mm2/s [102 SUS] and a temperature of 50° C [122° F] were used.

PVEO

		PV	EO
	rated	12 V DC	24 V DC
Supply voltage UDC	range	11 V to 15 V	22 V to 30 V
	max.ripple	5	%

Reaction time PVEO (minus PVG 120)

Supply voltage	Function		PVEO ON/OFF s	PVEO-R ON/OFF s
Disconnected by	Reaction time from neutral position to max. spool travel	max.	0.235	0.410
means		rated	0.180	0.350
of neutral switch		min.	0.120	0.250
Disconnected by	Reaction time from max. spool travel to neutral position	max.	0.175	0.330
means		rated	0.090	0.270
of neutral switch		min.	0.065	0.250

PVEA. PVEH and PVES

and PVES
32 V
o 32 V
%
0.3 (0.17) A @ 24 V
U _{DC}
o 0.75 • U _{DC}
o 0.70 mA
ΚΩ
5) W
0.3 (C 1 U _{DC} 1 0.75 • 1 0.70 n KΩ



PVE Series 4 for PVG 32, PVG 100 and PVG 120 SAUER PVE Series 4 for PVG 32 Technical Information

Technical Data

Technical Data (continued)

Function	PVEP
Supply voltage Vbat range	11 - 32 V
Supply voltage Vbat max. ripple	5%
Supply voltage Vbat over voltage (max. 5 min)	36 V
PWM control range (duty cycle)	10 - 80%
PWM float position control	PWM_A = PWM_B = 90%
PWM frequency	100 - 1000 Hz
PWM input voltage swing	0 - Vbat
PWM Trigger point	70 % of Vbat
Input impedance (standard pull down)	5 k Ohm
Input capacitor	
Power consumption	7 W
Error voltage: Fault	Vbat
Error voltage: No Fault	< 2 V

All connector terminals are short-circuit protected, and protected against reverse connection (and their combinations).

Connecting error pins from two or more PVE's will cause the surveillance system to malfunction

A WARNING


It's up to the customer to decide on the required degree of safety for the system.

Reaction time PVEA, PVEH and PVES (minus PVG 120)

Supply voltage	Function		PVEA Prop. fine s	PVEH Prop. high s	PVES Prop. super s	PVEP PWM Ctrl s
Disconnected by	Reaction time from neutral position to max.spool travel	max.	0.500	0.230	0.230	0.230
means		rated	0.320	0.150	0.150	0.150
of neutral switch	position to max. spoor traver	min.	0.250	0.120	0.120	0.120
Disconnected by	Reaction time from max. spool travel to neutral position	max.	0.550	0.175	0.175	0.175
means		rated	0.400	0.090	0.090	0.090
of neutral switch		min.	0.300	0.065	0.065	0.065
	Reaction time from neutral position to max.spool travel	max.	0.500	0.200	0.200	0.200
Constant voltage		rated	0.320	0.120	0.120	0.120
		min.	0.250	0.050	0.050	0.050
	Reaction time from max. spool travel to neutral position	max.	0.250	0.100	0.100	0.100
Constant voltage		rated	0.200	0.090	0.090	0.090
	traver to freutral position	min.	0.150	0.065	0.065	0.065
Hysteresis ¹⁾ rate		rated	2%	4%	~ 0%	5%

¹⁾ Hysteresis is indicated at rated voltage and f=0.02 Hz for one cycle (one cycle = neutral ->full A -> full B -> neutral.







Technical Data

Technical Data (continued)

Oil consumption PVEO

Supply voltage	Function		PVEO ON/OFF
Without voltage	Pilot oil flow per PVE	neutral*	0 l/min [0 US gal/min]
		1 1 1	0.1 l/min [0.026 US gal/min] 0.7 l/min
With	Pilot oil	locked*	
voltage	flow per PVE		
		continuous actuations*	[0.185 US gal/min]

^{* 12} bar and 21 mm2/s [174 psi and 101.9]

Oil consumption PVEA. PVEH and PVES

Supply voltage	Function		PVEA Prop. fine	PVEH Prop. high	PVES Prop. super
Without	Pilot oil flow per	neutral*	0 l/min	0 l/min	0.3 l/min
voltage	PVE		[0 US gal/min]	[0 US gal/min]	[0.106 US gal/min]
		locked* t oil flow	0.4 l/min	0.1 l/min	0.1 l/min
With	Pilot oil flow		[0.106 US gal/min]	[0.026 US gal/min]	[0.026 US gal/min]
voltage	per PVE continuous	1.0 l/min	0.7 l/min	0.8 l/min	
		actuations*	[0.264 US gal/min]	[0.185 US gal/min]	[0.211 US gal/min]

^{* 12} bar and 21 mm2/s [174 psi and 101.9]

Oil viscosity

	range	12 - 75 mm²/s [65 - 347 SUS]
Oil viscosity	min.	4 mm²/s [39 SUS]
	max.	460 mm²/s [2128 SUS]

Note: Max. start up viscosity 2500 mm²/s

Oil temperature

	Rec. range	30 - 60°C [86 -140°F]
Oil -temperature	min.	-30°C [-22°F]
		90°C [194°F]

Filtering

hydraulic system	Max. allowed degree of contamination (ISO 4406, 1999 version): 23/19/16

Ambient temperature

Ambiant				
temperatur	-30°	+60°C [-22°	+140°F]	
range Rec.		-	-	




Technical Data

Technical Data (continued)

Pilot pressure

Pilot pressure (relative to T pressure)	nom.	13.5 bar [196 psi]
	min.	10 bar [145 psi]
	max.	15 bar [217 psi]



Enclosure and connector

Version with Hirschmann connector	
Grade of enclosure *	IP 65

Version with AMP JPT connector	
Grade of enclosure *	IP 66

^{*} According to the international standard IEC 529

NB: In particulary exposed applications, protection in the form of screening is recommended.

Enclosure and connector

Version with Deutsch connector	
Grade of enclosure *	IP 65 / IP 69 K



SAUERPVE Series 4 for PVG 3. Technical Information PVE Series 4 for PVG 32, PVG 100 and PVG 120 Fault Monitoring System

The Fault Monitoring System

A fault monitoring system is provided in all PVEA, PVEH and PVES modules. The system is available in two versions:

- The active fault monitoring type, which provides a warning signal, deactivates the solenoid valves and drives the spool in neutral.
- The passive fault monitoring type, which provides a warning signal only. Both active and passive fault monitoring systems are triggered by three main events:

1. Input signal monitoring

The input signal voltage is continuously monitored. The permissible range is between 15% and 85% of the supply voltage. Outside this range the section will switch into an active error state.

2. Transducer supervision

If one of the wires to the LVDT sensor is broken or short-circuited, the section will switch into an active error state.

3. Supervision of the closed loop

The actual position must always correspond to the demanded position (input signal). If the actual spool position is further than the demanded spool position (>12%, PVEA: >25%), the system detects an error and will switch into an active error state. On the other hand, a situation where the actual position is closer to neutral than that demanded will not cause an error state. This situation is considered "in control". When an active error state occurs, the fault monitoring logic will be triggered:

Active fault monitoring

- A delay of 500 ms (PVEA: 750 ms) before anything happens.
- The solenoid valve bridge will be disabled and all solenoid valves will be released.
- An alarm signal is sent out through the appropriate pin connection.
- This state is memorized and continues until the system is actively reset (by turning off the supply voltage).

Passive fault monitoring

- A delay of 250 ms (PVEA: 750 ms) before anything happens.
- The solenoid valve bridge will not be disabled but still control the main spool position.
- An alarm signal is sent out through the appropriate pin connection.
- This state is not memorized. When the erroneous state disappears, the alarm signal will turn to passive again. However, the signal will always be active for a minimum of 100 ms when triggered.

To prevent the electronics from going into an undefined state, a general supervision of the power supply and the internal clock frequency is made. This function applies to PVEA, PVEH and PVES - and will not activate fault monitoring:

- 1. High supply voltage The solenoid valves are disabled when the supply voltage exceeds 36 V, and the main spool will return/stay in neutral.
- 2. Low supply voltage:

The solenoid valves are disabled when the supply voltage falls below 8.5 V, and the main spool will return/stay in neutral.



PVE Series 4 for PVG 32, PVG 100 and PVG 120 SAUER PVE Series 4 for PVG 32 Technical Information **Fault Monitoring System**

The Fault Monitoring System (continued)

3. Internal clock

The solenoid valves are disabled when the internal clock frequency fails, and the main spool will return/stay in neutral.

▲ WARNING

It's up to the customer to decide on the required degree of safety for the system (see page 21).

Fault Monitoring Overview


Туре	Fault monito- ring	Delay before error out	Error mode	Error output status	Fault output on PVE 1)	LED light	Memory (reset needed)
PVEO	No fault monitoring	-	-	-	-	-	-
			No fault	Low	< 2 V	Green	-
	Active	500 ms (PVEA: 750ms)	Input signal faults	High	U _{DC}	Flashing red	Yes
	Active		Transducer (LVDT)			Constant red	
PVEA			Close loop fault			Constant red	
PVEH PVES			No fault	Low	< 2 V	Green	-
	250 ms Passive (PVEA: 750ms)		Input signal faults	High	High ~U _{DC}	Flashing red	
		(PVEA: 750ms)	Transducer (LVDT)			Constant red	No
			Close loop fault				

¹⁾ Measured between fault output pin and ground




General Dimensions

PVE with Hirschmann connector




PVE with AMP connector





General Dimensions (continued)

PVE with deutsch connector





PVE Series 4 for PVG 32, PVG 100 and PVG 120

Technical Information

Connection and Activation


AMP-Version ON/OFF

Function	Signal voltag A (pin 1)	ge (A or B) B (pin 2)
Neutral	0	0
Q: P -> A	U _{DC}	0
Q: P -> B	0	U _{DC}


On DI versions two U_{DC} connections $(U_{DC}$ and $U_{DC2})$ are necessary.

- U_{DC2} will supply the electronics
- U_{DC} will supply the solenoid valves two ground pins (pin 3) are internally connected.

With advantages two separate power supplies can be used, see also system safety page 25.



157-498.12




AMP-Version Proportional

Function Signal voltage (U		Signal voltage (U _s)
	Neutral	$U_s(pin 1) = 0.5 \cdot U_{DC}$
	Q: P -> A	U_s (pin 1) = (0.5 -> 0.25) • U_{DC}
	Q: P -> B	U_{S} (pin 1) = (0.5 -> 0.75) • U_{DC}


On DI versions two U_{DC} connections $(U_{DC}$ and $U_{DC2})$ are necessary.

- U_{DC} will supply the electronics
- U_{DC2} will supply the solenoid valves two ground pins (pin 3) are internally connected.

With advantages two separate power supplies can be used, see also system safety page 25.




157-500.10



P301 106

Hirschmann-Version ON/OFF

Function	Signal voltage (A or B) A (pin 1) B (pin 2)		
Neutral	0	0	
Q: P -> A	U _{DC}	0	
Q: P -> B	0	U _{DC}	






PVE Series 4 for PVG 32, PVG 100 and PVG 120 $\,$

Technical Information

Connection and Activation


Hirschmann-Version Proportional

Function	Signal voltage (U _s)	
Neutral	$U_{s}(pin 2) = 0.5 \cdot U_{DC}$	
Q: P -> A	$U_s(pin 2) = (0.5 -> 0.25) \cdot U_{DC}$	
Q: P -> B	$U_s(pin 2) = (0.5 -> 0.75) \cdot U_{pc}$	




Deutsch-Version ON/OFF

Function	Signal volta A (pin 1)	nge (A or B) B (pin 4)
Neutral	0	0
Q: P -> A	U _{DC}	0
Q: P -> B	0	U _{DC}



Deutsch-Version Proportional


Function	Signal voltage (U _s)	
Neutral	$U_s(pin 1) = 0.5 \cdot U_{DC}$	
Q: P -> A	U_s (pin 1) = (0.5 -> 0.25) • U_{DC}	
Q: P -> B	$U_s(pin 1) = (0.5 -> 0.75) \cdot U_{DC}$	



On DI versions two U_{DC} connections $(U_{DC}$ and $U_{DC2})$ are necessary.

- U_{DC} will supply the electronics
- U_{DC2} will supply the solenoid valves two ground pins (pin 3) are internally connected.

With advantages two separate power supplies can be used, see also system safety page 25.



P301 105



PVE Series 4 for PVG 32, PVG 100 and PVG 120


Technical Information

Connection and Activation

AMP-Version Float Option for PVBZ

Function	U _s (pin 1)	Float (pin 5)
Neutral	0.5 x U _{DC}	0
Q: P -> A	(0.5 -> 0.25) x U _{DC}	0
Q: P -> B	(0.5 -> 0.75) x U _{DC}	0
Float	None or any	- 11
rioat	voltages ≤ U _{DC}	U _{DC}


For further information, see 520L0567



AMP-Version CAN-bus

Function	CAN-message		
	Port flow: 0		
Neutral	Valve state: 0		
Q: P -> A	Port flow: 1 - 100%		
Q. I > A	Valve state: 1		
Q: P -> B	Port flow: 1 - 100%		
Q.1 / D	Valve state: 2		


For further information, see 520L0665



Deutsch-Version Float Option for PVBZ

Function	U _s (pin 1)	Float (pin 5)
Neutral	0.5 x U _{DC}	0
Q: P -> A	(0.5 -> 0.25) x U _{DC}	0
Q: P -> B	(0.5 -> 0.75) x U _{DC}	0
Float	None or any voltages ≤ U _{DC}	U _{DC}


For further information, see 520L0567



Deutsch-Version CAN-bus

Function	CAN-message	
Neutral	Port flow: 0 Valve state: 0	
Q: P -> A	Port flow: 1 - 100% Valve state: 2	
Q: P -> B	Port flow: 1 - 100% Valve state: 1	

For further information, see 520L0665






PVE Series 4 for PVG 32, PVG 100 and PVG 120

Connection and Activation

Deutsch-Version PVEP


Duty cycle A-signal (pin 1)	Duty cycle B-signal (pin 3)	Function
0%	0%	
0 - 10%	0%	Neutral
0%	0 - 10%	
≥10%	≥10%	Fault (error)
0%	10 - 80%	P - B
10 - 80%	0	P - A



Float Option for PVEP - F

Duty cycle A-signal (pin 1)	Duty cycle B-signal (pin 3)	Function	
0%	0%		
0 - 10%	0%	Neutral	
0%	0 - 10%		
≥10%	≥10%	Fault (error)	
0%	10 80%	P - B	
0%		0 5.5 mm	
10 80%	0%	P - A	
10 80%	0 70	0 5.5 mm	
90%	90%	Float A-port	
90%	90%	(8 mm)	
≥90%	0%	Fault (error)	
0%	≥90%	Fault (error)	








Activation Characteristic

Standard Main Spools

Characteristics; oil flow, spool travel and voltage

The spools have 7 mm spool travel in direction A and 7 mm travel in direction B:

- 7 mm [0.27 in] spool displacement in direction A gives max. oil flow to port A
- 7 mm [0.27 in] spool displacement in direction B gives max. oil flow to port B






Activation Characteristic

Float Spools, PVBS

Characteristics; oil flow, spool travel and voltage

The spools have 4,8 mm spool travel in direction A and 8 mm travel in direction B:

- 4.8 mm [0.19 in] spool displacement in direction A gives max. oil flow to port A
- 4.8 mm [0.19 in] spool displacement in direction B gives max. oil flow to port B
- 8 mm [0.32 in] spool displacement in direction B gives completely open float position A/B → T.






Activation Characteristic

Float Spools, PVBZ

Characteristics; oil flow, spool travel and voltage

The spools have 5.5 mm spool travel in direction A and 8 mm travel in direction B:


- 5.5 mm [0.19 in] spool displacement in direction A gives max. oil flow to port A
- 5.5 mm [0.19 in] spool displacement in direction B gives max. oil flow to port B
- 8 mm [0.32 in] spool displacement in direction A gives completely open float position A/B → T.





Direction Indicator

Direction Indicator



	A-port B-port		
Direction signals "a1", "a2"	$-0.8 \pm 0.4 \text{mm} [0.031 \pm 0.015 \text{in}]$ $0.8 \pm 0.4 \text{mm} [0.031 \pm 0.015 \text{in}]$		
Max.load of "Dir_A","Dir_B"	50 mA		
Voltage "High" value with load of "Dir_A" or "Dir_B" = 20 mA	Minimum. U _{DC} - 1.5 V		
Voltage "High" value with load of "Dir_A" or "Dir_B" = 50 mA	Minimum. U _{DC} - 2.0 V		
Voltage "Low" value	Maximum: 0.2 V		


As shown in the figure, both "Dir_A" and "Dir_B" signals are "High" when the spool is in Neutral position. When the spool is moving in the A direction, the "Dir_A" signal goes "Low" and the "Dir_B" signal stays "High". The reverse is true when the spool is moved in the B direction.



Electrical Systems

Examples of Use

Signal wires must not be used to connect the power supply unless the distance between PVE and terminal board is < 3 m [120 in] and the wire cross-section is $\geq 0.75 \text{ mm}^2$ [0.001 in²].



:Emergency stop - : Signal leads

- : Supply leads



A WARNING

All marks and all types of directional control valves – inclusive proportional valves – can fail and cause serious damage. It is therefore important to analyse all aspects of the application.

Because the proportional valves are used in many different operation conditions and applications, the manufacturer of the application is alone responsible for making the final selection of the products – and assuring that all performance, safety and warning requirements of the application are met.


The process of choosing the control system – and safety level – could e.g. be governed by EN 954-1 (Safety related parts of control system).

Building in Safety

Example 1:

Proposal for a system with continuous monitoring and detection:

- PVE with DI function (Direction Indicator) and active fault monitoring
- 2 separate power supplies one for the PVE function and one for the DI function
 - make it possible to interrupt the PVE function without losing the DI function. E.g. the machine operator can activate the emergency stop device and stop the function
 - but still have the DI signal active for the overall safety system (e.g. a controller).
- The overall safety system (e.g. a controller) uses the fault indication from the DI function or the fault monitoring to interrupt the valve function (e.g. dump the pump flow).






System Safety

Example (continued)

Example 2:

Proposal for a system with fault monitoring and detection:


- PVE with active fault monitoring
- The fault monitoring can be used to interrupt the valve function (e.g. dump the pump flow).
- Activation of the emergency stop device will stop the function but also disconnect the fault monitoring system.



Example 3:

Simple system without fault monitoring and detection:

- PVEC
- Activation of the emergency stop device will stop the function



157-556.11

SAUER PVE Series 4 for PVG 32, PVG 100 and PVG 120 Technical Information **Code Numbers**

Code Numbers for Use on PVG 32 157B....

PVE for PVG 32 and PVG 100

PVEO, ON/OFF actuation Code no. 157B		Hirschman 12 V	n connector 24 V	AMP coi 12 V	nnector 24 V	Deutsch o	connector 24 V
	ON/OFF	4216,4266*	4228, 4268*	4901	4902,4272*	4291	4292
PVEO	ON/OFF with ramp	4217	4229	4903	4904	Not available	Not available
	PVEO-DI	Not available	Not available	4905	4906	Not available	Not available

PVEA/PVI Code no.	EH/PVES, proportional actuation 157B	Hirschmann connector 11 - 32 V	AMP connector 11 - 32 V	Deutsch connector 11 - 32 V
	Standard, active fault monitoring	Not available	4734	4792
PVEA	Standard, passive fault monitoring	Not available	4735,4775*	Not available
	Standard, active fault monitoring	Not available	4736	4796
PVEA-DI	Standard, passive fault monitoring	Not available	4737	Not available
	Standard, active fault monitoring	4032	4034,4074*	4092
PVEH	Standard, passive fault monitoring	4033,4073*	4035,4075*	4093
	Float, active fault monitoring	4332	Not available	4392
	Standard, active fault monitoring	Not available	4036	4096
PVEH-DI	Standard, passive fault monitoring	Not available	4037	Not available
	0% hysteresis, active fault monitoring	4832	4834	4892
PVES	0% hysteresis, passive fault monitoring	4833	4835,4865*	Not available

^{*} Anodized versions

PVED-CC, proportio	anl actuation	AMP connector	Deutsch connector	
Code no. 157B		11 V 32 V	11 V 32 V	
PVED-CC	ISOBUS	4943	4944	

PVEH-F, proportioar	nl actuation	AMP connector	Deutsch connector	
Code no. 157B		11 V 32 V	11 V 32 V	
PVEH-F	Float Active fault monitoring	4338	4398	

PVEP, proportioanl actuation		Deutsch connector 11 V 32 V	
PVEP	Active fault monitoring	11034832	
PVEP-F	Float Active fault monitoring	157B4753	



SAUER PVE Series 4 for PVG 32 Technical Information PVE Series 4 for PVG 32, PVG 100 and PVG 120 **Code Numbers**

PVE for PVG 120

PVEO/PVEH electrical actuation Code no. 155G		Hirschmann connector	AMP connector
PVEO	ON/OFF, 12 V	4272	4282
	ON/OFF, 24 V	4274	4284
PVEH	Standard, active fault monitoring	4092	4094
	Standard, passive fault monitoring	4093	4095

Notes



Notes

Notes



Our Products

Hydrostatic Transmissions

Hydraulic Power Steering

Electric Power Steering

Electrohydraulic Power Steering

Closed and Open Circuit Axial Piston Pumps and Motors

Gear Pumps and Motors

Bent Axis Motors

Orbital Motors

Transit Mixer Drives

Proportional Valves

Directional Spool Valves

Cartridge Valves

Hydraulic Integrated Circuits

Hydrostatic Transaxles

Integrated Systems

Fan Drive Systems

Electrohydraulics

Microcontrollers and Software

Electric Motors and Inverters

Joysticks and Control Handles

Displays

Sensors

Sauer-Danfoss Hydraulic Power Systems – Market Leaders Worldwide

Sauer-Danfoss is a comprehensive supplier providing complete systems to the global mobile market.

Sauer-Danfoss serves markets such as agriculture, construction, road building, material handling, municipal, forestry, turf care, and many others.

We offer our customers optimum solutions for their needs and develop new products and systems in close cooperation and partnership with them.

Sauer-Danfoss specializes in integrating a full range of system components to provide vehicle designers with the most advanced total system design.

Sauer-Danfoss provides comprehensive worldwide service for its products through an extensive network of Authorized Service Centers strategically located in all parts of the world.

Local address:

Sauer-Danfoss (US) Company 2800 East 13th Street Ames, IA 50010, USA Phone: +1 515 239-6000 Fax: +1 515 239 6618

Sauer-Danfoss GmbH & Co. OHG Postfach 2460, D-24531 Neumünster Krokamp 35, D-24539 Neumünster, Germany

Phone: +49 4321 871-0 Fax: +49 4321 871 122 Sauer-Danfoss ApS DK-6430 Nordborg, Denmark Phone: +45 7488 4444 Fax: +45 7488 4400

Sauer-Danfoss-Daikin LTD Sannomiya Grand Bldg. 8F 2-2-21 Isogami-dori, Chuo-ku Kobe, Hyogo 651-0086, Japan Phone: +81 78 231 5001 Fax: +81 78 231 5004